

TCP/IP DEMO GUI setup for PICEMnet 2



A Leading Provider of Smart, Connected and Secure Embedded Solutions



SMART | CONNECTED | SECURE

V1.3

15/3/2021

Tested in following environment :

MPLAB X v5.45

XC8 v2.32

ICD4 debugger


PICDEM net2 demoboard (DM163024)

Step1 (Hardware configuration)

- Connect the 9V power supply
- Connect the ICD4 programming tool to the PC (USB) and to the PICDEM net 2 RJ11 connector
- Connect an ethernet cable between your router and the RJ45 connector coming from PIC18F97J60 (the closest from the LCD display)
- Connect your Host PC to the router (WiFi or ethernet) and make sure they are in the same DHCP domain (see later step to check this)
- Optional : USB – UART cable (for TCP/IP console messages (e.g. MCP2200EV-VCP + USB mini to USB type A cable).

Use TERA TERM (<https://ttssh2.osdn.jp>) or any other open source terminal software as serial console.

Serial Setup : 115200,N,8,1



Step2

Open the project : **tcpClientDEMO.X** in the **TCPIP demo** directory

Select the **PICDEMnet2_ETH97J60** configuration

Step 3

Open the file **main.c**

Search for **HOST**

Enter your **HOST PC** IP address

Check / change the default port number **60**

Compile and program the PICDEM net2 demoboard

After, programming the PIC18F97J60, the LCD display should show the demoboard IP address

Step3

Launch the Microchip TCP/IP demo GUI **TCPIP_Demo_AN1921.jar**

Select the TCP Server Demo tab

Keep default / change **Port** with the same Port number as the one entered in your main file.


In STATUS field from the TCP/IP Demo GUI you should see :

Listen...

xxx.xxx.xxx.xxx : Connected

(NB : xxx.xxx.xxx.xxx is your board IP address shown on the LCD display)

USE_ENc97J60



Step5

In **Sent/Received Data** field from the TCP/IP Demo GUI you should see :


->: Temperature: 0x yy; LED: 0x yy; Buttons: 0xf; Pot: 0x yy

(values yy depend upon your local temperature, LEDs, button status and potentiometer position)

If you change these parameters, the values will change in real-time in the **Sent/Received Data** field from the TCP/IP Demo GUI .

Step6 : Control the Leds

By pushing any of the 8 buttons in the **LED Control** field from the TCP/IP Demo GUI you will light on the corresponding LED on the demoboard



Step5

In **Sent/Received Data** field from the TCP/IP Demo GUI you should see :

->: Temperature: 0x yy; LED: 0xyy; Buttons: 0xf; Pot:0xyyy

(values yy depend upon your local temperature, LEDs, button status and potentiometer position)

If you change these parameters, the values will change in real-time in the **Sent/Received Data** field from the TCP/IP Demo GUI .

Step6 : Control the Leds


By pushing any of the 8 buttons in the **LED Control** field from the TCP/IP Demo GUI you will lit on the corresponding LED on the demoboard

Step7 : Send a message to the LCD display

Type any message in the **Send** field from the TCP/IP Demo GUI .

Press the **Send** button

The message will appear on the 2nd line of the LCD display



OPTIONAL :

NB : the message logs are displayed at power on only.

After programming the application, power on the demoboard and after a few seconds some messages should be visible

In case you installed a USB-UART cable, you'll be able to see TCP/IP console messages like below if the link is successful :

(The IPv4 address shown is the demoboard IP address (it should be also visible on the PICDEMnet 2 LCD display)

A screenshot of a Tera Term VT terminal window. The window title is "COM7 - Tera Term VT". The menu bar includes "File", "Edit", "Setup", "Control", "Window", and "Help". The terminal output shows the following messages:

```
Starting Syslog at 49888
49888 : Waiting for Link
49888 : Link started
49888 : 0.0.0.0
49890 : 192.168.1.44
```